



ILL No.	PART No.	PART NAME	Quantity SP310 / SPL310		FORMER PART No.
STARTER MOTOR					
	23300-36900	ASS'Y - MOTOR, starter	1	1	23300-30100
1	23310-36900	ASS'Y - ARMATURE	1	1	23310-30100
2	23321-09900	WASHER - thrust	3	3	23339-30100 23382-30100
3	23339-09500	WASHER - thrust	1	1	23320-30100
4	23312-61000	ASS'Y - PINION & CLUTCH	1	1	23312-30101
5	23442-09600	SPRING - pinion sleeve (No. 1)	1	1	23315-30100
6	23443-09600	SPRING - pinion sleeve (No. 2)	1	1	23315-30100
7	23374-09500	SLEEVE - pinion	2	2	23374-30100
8	23372-09600	CLIP - sleeve pinion	2	2	23372-30100
9	23444-09600	STOPPER - spring sleeve	1	1	23314-30100
10	23351-09600	WASHER - pinion	1	1	23370-30100
11	23369-43600	STOPPER - pinion	1	1	
12	23373-43600	CLIP - stopper, pinion	1	1	
13	23370-09600	WASHER - stopper, pinion	1	1	
14	23383-09500	ASS'Y - BEARING, center	1	1	
15	23441-09500	BEARING - metal, center	1	1	
16	23450-09500	BRAKE	1	1	
17	23453-09500	SPRING - brake	1	1	
18	23446-36900	COVER - dust	1	1	
19	23322-09500	ASS'Y - LEVER, pinion shaft	1	1	
20	23323-09500	PIN - lever, shift	1	1	
21	23391-43300	PIN - cotter	1	1	

ILL No.	PART No.	PART NAME	Quantity SP310 / SPL310		FORMER PART No.
22	23337-09500	ASSY - COVER, rear	1	1	23337-30100
23	23338-09900	BEARING - metal	1	1	
24	23333-09900	SPRING - brush	4	4	23333-30100
25	23379-09900	BRUSH (-).....	2	2	23379-30100
26	23380-09902	BRUSH (+).....	1	1	23380-30100
27	23547-25660	SCREW (3 \emptyset)	2	2	
28	22103-50000	SCREW (4 \emptyset)	4	4	
29	23306-36900	ASSY - COIL, field	1	1	23306-30100
30	23305-09500	SCREW - set, pole core	4	4	
31	23384-09601	ASSY - TERMINAL	1	1	23384-30100
32	23342-09901	ASSY - COVER, brush	1	1	
33	23352-09600	BOLT - joint	2	2	23340-30100
34	23393-09900	NUT	2	2	
35	23447-36900	PLATE - connecting	1	1	
36	23343-36900	ASSY - SWITCH, magnetic	1	1	
37	2344536900	COVER - dust	1	1	23342-30100
38	22201-09600	BOLT (5 \emptyset)	2	2	
39	23318-36900	ASSY - CASE, gear	1	1	23318-30100
40	23319-09600	BEARING - metal	1	1	
To fix starter motor					
	1 24635-1	BOLT	2	2	(1-24635-1)
	9 15216 1	WASHER - lock	2	2	(9-15216)

ILL	PART No.	PART NAME	Quantity	FORMER
-----	----------	-----------	----------	--------

No.			SP310 / SPL310	PART No.
DISTRIBUTOR & ALTERNATOR MOUNTING				
23168-12200	ASS'Y - BRACKET, mounting, alternator		1 1	23168-32200
	to fix alternator to bracket			
1-14530-1	BOLT		2 2	1-34525-1
9-15115-1	WASHER - lock		2 2	9-15215-1
23172-12200	SPACER		1 1	
	To fix bracket to cylinder block			
1-11628	BOLT		1 1	
1-11616-1	BOLT			
9-15116-1	WASHER - lock		3 3	
22318-12200	ASS'Y - TUBE, conduit vacuum control		1 1	22318-10400
23174-12200	BAR - adjusting, alternator		1 1	23174-32200
	To fix bar to cylinder block			
1-14520-1	BOLT			
9-11145-1	NUT		1 1	
23173-12200	BRACKET - adjusting bar		1 1	
IGNITION COIL & HIGH TENSION CABLE				
22433-09400	COIL - ignition (HITACHI)		1 1	
22433-09500	COIL - ignition (HANSHIN)			22433-31304
22433-31300	COIL - ignition (HITACHI)		u1 1	
	To fix coil to dash			
3-14414-1	SCREW2		2 2	(3-14414-1)
9-15114-1	WASHER - lock			
9-15414-1	WASHER - plain		2 2	(9-15414-1)
22401-58000	PLUG - spark (N-G-K)		u-4 4	(22401-58000)
22401-32201	PLUG - spark (HITACHI)		4 -	22401-32200

ILL No.	PART No.	PART NAME	Quantity SP310 / SPL310	FORMER PART No.
---------	----------	-----------	----------------------------	--------------------

23500-12200	REGULATOR - voltage	1	1	23500-42200
	To fix regulator to hood ledge			
3-14416-1	SCREW	2	2	3-14420-1
9-15114-1	WASHER - lock	2	2	(9-15114-1)
22431-10560	RING - high tension cable	1	1	

WIRING

24012-12200	COMP - CABLE, engine room harness	1	1	24012-10401
24020-12200	ASS'Y - CABLE, generator	1	1	24020-10400
24013-12200	COMP. - CABLE, instrument harness	1	-	24013-10401
24013-12300	COMP. - CABLE, instrument harness	-	1	24013-10500

ELECTRIC UNIT

25150-12200	COMP. - SWJTCH, ignition & starter, with key	1	1	25150-09900
25160-10400	COMP. - SWITCH, lighting, without fog lamp's	1	1	
25160-10401	COMP. - SWITCH, lighting, with fog lamp's	1	1	(25160-10401)

METER

26460-10400	ASS'Y - LAMP, warning, turn signal (amber)	1	1	26461-08600
26451-08600	ASS'Y - LAMP, warning, main beam (red)	1	1	(26451-08600)

W/S WIPER & WASHER

26340-12200	ASS'Y - WIPER DRIVE, W/S	1	1	26340-10400
26345-10400	ASS'Y - FLAME, wiper drive	1	1	(26345-10400)
26347-10400	CASHING - flexible wire	1	1	(26347-10400)
26348-10400	CASHING - outer, wind screen	1	1	26348-30001
26355-12200	ASS'Y - MOTOR, WAS wiper drive	1	1	26355-10400

ILL No.	PART No.	PART NAME	Quantity SP310 / SPL310	FORMER PART No.
---------	----------	-----------	----------------------------	--------------------

26371-10400	ASS'Y - BOX, wheel, W/S wiper	2	2	126371-104001
27400-12200	KIT - W/S WASHER	1	-	27400-10400
27400-12201	KIT - W/S WASHER	u-1	-	27400-10401
27400-12300	KIT - W/S WASHER	-	1	274C0-10500

LAMP

26120-10400	ASS'Y - LAMP, parking & turn signal	2	2	(26120-10400)
26120-10401	ASS'Y - LAMP, parking & turn signal (amber)	-	2	(U.S.A. only)
26121-10400	ASS'Y - LENS, parking & turn signal lamp	2	2	(26121-10400)
26121-10401	ASS'Y - LENS, parking & turn signal lamp (amber)	-	2	(U.S.A. only)
26123-10400	SEAT - rubber	2	2	(26123-10400)
26127-04100	PACKING - washer	2	2	(26127-04100)
2671504200	BULB	2	2	(26715-04200)
9-98812-1	SCREW	2	2	(9-98812-1)
9-15110-1	WASHER - lock	6	6	(9-15110-1)
9-11110-1	NUT	6	6	(9-11110-1)

CAR HEATER

27010-12200	KIT - HEATER, car	1	-	27010-10400
27010-12300	KIT - HEATER, car	-	1	27010-10400

RADIO

27310-12200	SET - RADIO	1	-	27310-10400
27310-12300	SET - RADIO	-	1	27310-10500

ILL No.	PART No.	PART NAME	Quantity SP310 / SPL310	FORMER PART No.
---------	----------	-----------	----------------------------	--------------------

TRANSMISSION

32010-12250	ASSY - TRANSMISSION, with clutch lever	1	1	32010-10450
32101-12200	CASE - transmission	1	1	32101-10400
32114-00100	STUD (to fix front cover)	7	7	2-84520
32291-09500	WASHER - lock	1	1	32291-00100
32213-12200	GEAR - counter shaft (29 T)	1	1	32213-27160(31T)
32201-12200	GEAR - main drive (21 T)	1	1	32201-10400(20T)
32246-02700	WASHER - thrust, main shaft, rear	1	1	32246-26760
32150-01300	STICK, oil level dip	1	1	32150-03200
32865-12200	SHIELD - dust, change lever	1	1	32869-03200

HAND BRAKE CONTROL

36010-10401	CONTROL, hand brake	1	1	36010-10400
36310-10401	LEVER, hand brake	1	1	36310-10400
36327-04101	ROD - release, hand brake	1	1	(36327-04101)
36330-04100	SPRING - release rod	1	1	(36330-04100)
36329-04100	BUTTON - release, hand brake	1	1	(36329-04100)
36332-04100	PAWL - ratchet	1	1	(36332-04100)
36339-04100	PIN - pawl	1	1	(36339-04100)
41058-10360	WASHER - "C" type	1	1	(41058-10360)
36320-10401	PLATE - ratchet	1	1	(36320-10400)